


# C10- PARALLEL PORT INTERFACE CARD

## Rev. 8

### User manual Rev. 1



## 1. Overview

This card provides an easy way of interfacing your inputs and outputs from you parallel port. It provides terminals for the connections and conditions the signals for use in CNC applications.

## 2. Features

- **Buffered inputs and outputs.** Outputs are buffered through the use of high speed and high current buffers allowing the card to output the signals without using the power from the parallel port. It can take the +3.3 or +5vdc signal from the parallel port and deliver solid +5vdc at 24 milliamps.
- **Bidirectional pins 2-9.** By selecting the appropriate jumper setting you can use these pins for input or output. If you use a second parallel port and set it to work in a bidirectional way, you get a total of 34 I/O pins.
- **Output pins 1, 2, 3, 4, 5, 6, 7, 8, 9, 14, 16, 17. Or 1, 14, 16, 17.**

- **Input pins 10, 11, 12, 13, 15. Or 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 15.**
- **Input and output pins with close by ground or +5vdc connections**
- **The common terminal to pins 2-9 can be ground or +5vdc.** Forget about grounding problems. Easily connect your pin by using your close by ground connection. No need to be an electronics expert to ground all your stuff. The board has a jumper that allows you to select if the common terminal to pins 2-9 will carry a ground or +5vdc. So if you are connecting encoders or proximity switches, you can select it to ground. If you are connecting Geckodrives or limit switches, you can set it to be +5VDC.
- **External Enable Pin (EN).** The board has a pin that allows you to enable/disable all the outputs at once. The board requires +5vdc in the EN pin. If it is not present, it will send all the outputs to ground. You can use this to enable or disable the system manually, or you can install an external Safety Charge Pump or other external safety monitoring device.
- **Works directly with popular CNC hardware and software.** Such as Geckodrive, DeskCNC or Rutex, and parallel port control software, such as mach2, Linux EMC, TurboCNC, CNCPlayer, CNCZeus and others. (Not all tested).
- **All TTL 5VDC signals.** Interface directly with parallel port interface products and other CNC4PC cards. 5VDC (TTL) cards are very common among automation devices.
- **Screw-On connections for all terminals.** You only have to screw-on the wires to make all your connections.


### 3. Specifications.

DIGITAL INPUT SPECIFICATIONS	
On-state voltage range	2 to 5V DC
Minimum on-state input current	1.1 mA
Maximum off-state voltage	0.8V
Maximum off-state current	1.1 mA
Maximum operation frequency	4 MHz
Typical signal delay	10nS

DIGITAL OUTPUT SPECIFICATIONS	
Maximum output voltage	(5V power supply voltage) + 0.5V
Typical output current	24mA
Maximum off-state voltage	0.44 V
Maximum operation frequency	4 MHz
Typical signal delay	10 nS
Time of transition to high impedance state	12 nS*

\*Time passed since a low in the ENABLE input is detected and the outputs are disabled.

## 4. Board description




### 4.1 Using configuration jumper.

#### 4.1.1 Using the COM configuration jumper.

This is for selecting the value to get at the COM terminals found next to step and direction terminals (Pin 2-9). Some drivers expect a ground, and others expect +5vdc. There is a jumper (X7) that allows you to select +5VDC or GND for the COM pins.


- 1-2: COM= GND**
- 2-3: COM= 5V**



### 4.1.2 Using the Pins 2-9 direction jumper.

There is a jumper (X6) to select the pins 2-9 direction.

- 1-2: **OUTPUTS**
- 2-3: **INPUTS**




### 4.1.3 Enable pin.

The card must be provided with a 5VDC signal to enable operation. This feature has been added to enable you to control externally the status of the outputs of the card. You can add an external switch or a Safety Charge Pump to provide the enabling signal. When the enable signal is not enabled, output signals sent high impedance state. If you need the communication to be enabled at all times you can provide the 5 volts directly from the source that is powering the card.

#### **Wiring:**

The Parallel Port Interface Card has a very basic design that provides the flexibility you look for on CNC projects.



**WARNING:** This card must have the power supplied while it is connected to the PC. If power is removed to the card while it is connected to the PC, noise can be introduced to the output lines. This can create a dangerous situation as relays or other devices that might be connected to this card could get activated.

## 5. Connection instructions

### ***Requirements:***

It requires a 5VDC @ 400 milliamps power supply to operate. This power can be taken from the computer's power supply or USB port. Consider using the A3 – USB Power Cable found under Accessories in the website.



### **WARNING**

Check the polarity and voltage of the external power source and connect the 5V and GND (X1). Overvoltage or reverse-polarity power applied to these terminals can cause damage to the board, and/or the power source. Follow the steps below.

**Step 1.** Set the configuration jumpers (X4 and X6) as are required by your system.

**Note:** Is important to understand the selection jumper functions (see section 4.1).

**Step 2.** Ensure that all external power sources are set to **OFF**.

**Step 3.** Connect the power supply to the Power Inputs Connectors (X1).

**Step 4.** Connect the parallel cable coming from the PC to the Female DB25 Connector (X3).

**Step 5.** Connect to the board the components of the system.

**Step 6.** Turn on the external supplies and check that the power led indicator (X2) lights.

**Step 7.** Apply 5V to the enable pin (X5) to activate the outputs.

## 6. Functional Block Diagrams

### 6.1 Bidirectional pins simplified block diagram




Fig. 1 Simplified functional block diagram for the 2-9 pins.

### 6.2 Outputs simplified block diagram




Fig. 2 Simplified functional block diagram for the outputs.

### 6.3 Dedicated Inputs simplified block diagram




Fig. 3 Simplified functional block diagram for the inputs.

## 7. Wiring diagrams

Different kind of sensors and switches can be connected to inputs board, but this board support only TTL signal. If you need to connect devices that generate 12V or 24V signals in some cases is necessary add external resistors.

**Note.** The below wiring diagrams are an example, any input can be used for the connections.

### 7.1 Connecting Switches or push button.




Fig. 3 Wiring diagram to connect switches.

### 7.2 Connecting NPN sensors.




Fig. 4 Wiring diagram to connect NPN open collector proximity sensors.




Fig. 5 Wiring diagram to connect in parallel NPN open collector proximity sensors.

Connecting NPN open collector proximity sensor with the C10	
R1 Value (12V)	R1 Value (24V)
Aprox. 10KΩ	Aprox. 25KΩ




Fig. 6 Wiring diagram to connect NPN proximity sensors with internal pull up resistor.

Some NPN proximity sensor has a pull-up resistor (R1) internally. It is necessary to know its value in order to connect safely the sensor with the BOB. Follow this recommendation:

Connecting NPN open collector proximity sensor with the C10	
(R1+R2) Value (12V)	(R1+R2) Value (24V)
Aprox. 10K $\Omega$	Aprox. 25K $\Omega$

### 7.3 Connecting PNP sensors.




Fig. 7 Wiring diagram to connect PNP proximity sensors

Connecting PNP proximity sensor with the C10	
R Value (12V)	R Value (24V)
Aprox. 10K $\Omega$	Aprox. 25K $\Omega$

#### 7.4 Other connection.




Fig. 8 Wiring diagram to do an “Auto Tool Zero”

Other wiring diagrams samples are shown in the next links.

[http://cnc4pc.com/Tech\\_Docs/E\\_STOP\\_N\\_EN\\_Wiring.pdf](http://cnc4pc.com/Tech_Docs/E_STOP_N_EN_Wiring.pdf)

[http://cnc4pc.com/Tech\\_Docs/E\\_STOP\\_N\\_SCHP.pdf](http://cnc4pc.com/Tech_Docs/E_STOP_N_SCHP.pdf)

[http://cnc4pc.com/Tech\\_Docs/C10R8\\_WD2.pdf](http://cnc4pc.com/Tech_Docs/C10R8_WD2.pdf)

## 7. Troubleshooting.

### SYMPTOM 1: THE BOARD DOES NOT REACT TO THE SIGNAL.

POSSIBLE CAUSE	POSSIBLE SOLUTIONS
<ul style="list-style-type: none"> <li>- <b>Pin conflict or mach3 configuration.</b> It is possible that the port address used for the pin is not right, or that there is a pin conflict with the. That is that you are using that same pin twice. (it could be assigned to a different function).</li> </ul>	<ul style="list-style-type: none"> <li>- Go to the device manager in windows, and check the memory address used for the parallel port you are using. Usually it will be 378 for LPT1. Check also that the port does not have a conflict. Then in mach3, go to Ports &amp; Pins / Port Setup and Axis Selection. Check the memory address is correct.</li> <li>- Check that the pin you are using is not been used anywhere else in your setup. Got to motor output and output signals, and check all the entries.</li> </ul>
<ul style="list-style-type: none"> <li>- <b>The board does not like the waveform it is getting.</b> Some breakout boards could invert the signals or modify the pulse width. Changing the active low status of the pin used also inverts the waveform.</li> </ul>	<ul style="list-style-type: none"> <li>- Play with the active low status of the pin used for the frequency.</li> </ul>
<ul style="list-style-type: none"> <li>- <b>The signal or frequencies are not getting to the board.</b> It could be the cable or that you are passing the signal through the same breakout board that you are enabling/disabling, so the outputs could be disabled, so they will not get to the breakout board.</li> </ul>	<ul style="list-style-type: none"> <li>- Try a different cable.</li> <li>- Test the pins in the cable (before they reach the breakout board) with a multimeter.</li> </ul>
<ul style="list-style-type: none"> <li>- <b>Problems with Mach3 Pulse Generation.</b> Mach3 could have installation problems (you did not restart immediately after installation), or there could be something creating a conflict. Some dongle devices might cause this, other software, like QuickTime or drivers for touch screen.</li> </ul>	<ul style="list-style-type: none"> <li>- Test this in a different PC.</li> <li>- Follow Art's suggestions for optimizing up WinXP:  <a href="http://www.machsupport.com/downloads/XP_Optimization.txt">http://www.machsupport.com/downloads/XP_Optimization.txt</a>.</li> </ul>

**SYMPTOM 2: THE OUTPUTS DO NOT GET ENABLED / NO SIGNALS ARE COMING OUT.**

POSSIBLE CAUSE	POSSIBLE SOLUTIONS
<ul style="list-style-type: none"> <li>- <b>The EN terminal (Enable Outputs) is not enabled.</b> The board requires to be externally enabled.</li> <li>- <b>The parallel cable is not well connected to the PC parallel port.</b></li> </ul>	<ul style="list-style-type: none"> <li>- Make sure you are providing +5vdc to the EN terminal. This +5vdc can be taken from the terminal next to it.</li> <li>- Check if the parallel port is well connected to the PC.</li> </ul>

**SYMPTOM 3: THERE IS NOISE IN THE SYSTEM, OR THE MOTORS DO NOT MOVE SMOOTHLY.**


POSSIBLE CAUSE	POSSIBLE SOLUTIONS
<ul style="list-style-type: none"> <li>- <b>The board could be underpowered.</b></li> </ul>	<ul style="list-style-type: none"> <li>- Make sure you are using a +5vdc 400mA power supply.</li> </ul>
<ul style="list-style-type: none"> <li>- <b>There could be a short that could be draining the power to the board.</b></li> </ul>	<ul style="list-style-type: none"> <li>- Check that there are no hot spots in the board or it's connections.</li> <li>- Measure the board's power consumption, it should be less than 400mA (depending on the features used).</li> <li>- Blown chips could create an internal short and end up drawing power that can affect how other chips work.</li> </ul>
<ul style="list-style-type: none"> <li>- <b>There could be an external noise source that could be introducing noise into the system.</b></li> </ul>	<ul style="list-style-type: none"> <li>- Try using shielded cables.</li> <li>- Try to isolate VFDs or AC servos, etc.</li> <li>- Try using 103. 0.1mF caps between the I/O terminal and a ground of the board.</li> </ul>

**SYMPTOM 5: A I/O PIN MIGHT NOT BE WORKING.**

POSSIBLE CAUSE	POSSIBLE SOLUTIONS
<ul style="list-style-type: none"> <li>- <b>A chip may have gone bad.</b> These buffers could act as fuses for the signals, and they can go bad because of noise spikes or even strong static.</li> </ul>	<ul style="list-style-type: none"> <li>- These chips are inexpensive and readily available. You can order them here: <a href="http://www.cnc4pc.com/Store/osc/index.php?cPath=38_43">http://www.cnc4pc.com/Store/osc/index.php?cPath=38_43</a>.</li> <li>- Carefully moving chips around and checking if the problem moves around</li> </ul>

	could be a way of figuring out if this is the case.
- <b>There could be a problem with the parallel cable or parallel port.</b>	- Test this with a different PC or parallel port.

## 8. Dimensions.



All dimensions are in Millimeters.

### Disclaimer:

Use caution. CNC machines could be dangerous machines. DUNCAN USA, LLC or Arturo Duncan are not liable for any accidents resulting from the improper use of these devices. The C10 is not fail-safe device, and it should not be used in life support systems or in other devices where its failure or possible erratic operation could cause property damage, bodily injury or loss of life.