



# MAGNETIC PANEL LINEAR AMPLIFIER



- TB1 - 1 — +24 vdc
- 2 — +18 vdc
- 3 — -18 vdc
- 4 — +8 vdc
- 5 — } 18 vac
- 6 — }
- 7 — GND
- 8 — GND



MAINTENANCE MANUAL

GND