



Easy to adjust

1. Loosen of fixed auxiliary nut on main nut.



2. Counterclockwise spin auxiliary nut half-round and clockwise lock

