

### Slave Axis Selection

X Axis

Slaved Axis

☐ A Axis

☐ B Axis

☐ C Axis

☒ None

Y Axis

Slaved Axis

☐ A Axis

☒ B Axis

☐ C Axis

☐ None

Z Axis

Slaved Axis

☐ A Axis

☐ B Axis

☐ C Axis

☒ None

Restart Mach3 after resetting these selections

OK

### Backlash Values

Backlash Distance in units

X Axis

Y Axis

Z Axis

A Axis

B Axis

C Axis

Backlash Speed % of Max

☐ Backlash Enabled

Restart program to save these settings

OK Cancel

### PlugIn Control and Activation

Enabled	PlugIn Name	Config
	ESS_Mach3	CONFIG
	Flash-FlashScreen-SWF-PlugIn-A.Fenerty--...	CONFIG
	JoyStick-JoyStick-PlugIn--Art-Fenerty-Ver-...	CONFIG
	PrinterScope-Port-Scope-1.00.046	CONFIG
	TurnDiags-Turn-Diags-1.00.1	CONFIG
	Video---B.Barker-Ver-1.0	CONFIG

OK

### Pulley Selection

Current Pulley	Min Speed	Max Speed	Ratio
<input type="text" value="Pulley Number 1"/>	<input type="text" value="7990"/>	<input type="text" value="24000"/>	<input type="text" value="1"/>

☐ Reversed

OK

Port for an Output found as not port 1 or port 2. Unless using ModBus, this is wrong.  
 Port for an Output found as not port 1 or port 2. Unless using ModBus, this is wrong.  
 Port for an Output found as not port 1 or port 2. Unless using ModBus, this is wrong.  
 ///////////////End of OUTPUT Signals Check////////////////////////

///////////////// Digitising Probe //////////////////////////  
 Digitising Probe Pin setting may be wrong  
 It should be pins 10-13 or 15. Check it before use!.  
 ///////////////End of Probe Check //////////////////////////!

//////////Motor Settings - Enabled Motors only are Checked////////////////////////!.

A motor Direction pin is set to a port other than 1 or 2, this is probably an error..  
 //////////Motor Settings - End of Motor Checks////////////////////////!.

Checkup complete , please check any errors listed.

Thank you for checking your Settings.....